

SONY®

Osebni zvočni sistem

BLUETOOTH® Kratka navodila za uporabo

SL



ICF-CS20BT/XDR-DS21BT




* 4 4 6 8 4 0 9 1 1 * (1)

4-468-409-11(1)
©2013 Sony Corporation

V namene prikaza delovanja je uporabljen model ICF-CS20BT.


1



Pritisnite in držite, dokler ne zaslišite piskov in ne začne utripati simbol (BLUETOOTH)◀.

2

Android




Pritisnite [Settings]
→ [Bluetooth]

[Bluetooth]

[SONY: ICF-CS20BT] ali
[SONY: XDR-DS21BT]

iPhone



Pritisnite [Settings]
→ [Bluetooth]

→
 →

[SONY: ICF-CS20BT] ali
[SONY: XDR-DS21BT]

3

