




WALKMAN
NW-WS413/WS414


4-580-536-11(1) (BG)
©2016 Sony Corporation




1








2







3





«Вкл.»



Windows

Media Go
<http://mediago.sony.com/>

Mac

Content Transfer for Mac
<http://www.sony.net/ct-mac/>



http://rd1.sony.net/help/dmp/nwws410/h_ww/

