














A white icon on a blue background. It depicts a stylized person from the chest up, facing right. The person's right hand is raised, with the index finger pressing a circular button. Above the button is a speech bubble containing a power symbol (a circle with a vertical line through it).







)) Napajanje uključeno



 Reprodrukija



Uključeno



Windows

Media Go
<http://mediago.sony.com/>

Mac

Content Transfer for Mac
<http://www.sony.net/ct-mac/>



http://rd1.sony.net/help/dmp/nwws410/h_ww/

