





WALKMAN
NW-WS413/WS414



4-580-536-11(1) (LV)
©2016 Sony Corporation




1








2



3





“ieslēgts”

