










4-580-536-11(1) (SR)
©2016 Sony Corporation




1






2








Ⓢ) „Napajanje je uključeno“







3



)) „Reprodukcija“



„Uključeno“



Windows

Media Go
<http://mediago.sony.com/>

Mac

Content Transfer for Mac
<http://www.sony.net/ct-mac/>



http://rd1.sony.net/help/dmp/nwws410/h_ww/

