












# 1









# 2





Android / iPhone






# 3



hear on  
Wireless NC  
MDR-100ABN





**i**  
  
[http://rd1.sony.net/help/mdr/100abn/h\\_zz/](http://rd1.sony.net/help/mdr/100abn/h_zz/)